

OWNERS MANUAL



LUMOS Mozzie Zapper

10000463

www.oztrail.com.au

Designed & Imported by: Adventure Trading Australia Pty Ltd 71 Charles Ulm Place, Eagle Farm, QLD 4009 AUSTRALIA


P: 1300 362 921

www.oztrail.com.au

facebook.com\OZtrailAustralia



TECHNICAL SPECIFICATIONS



Lumen: 180 (High)

100 (Medium) 50 (Low)



Run time: High: 5hr Medium: 12hr Low: 30hr

Weight: 255g

LED: 1W - 2835 SMD

UV LED: 3 x 0.06W

UV run time: 40hr

Attractant working time: 25 to 30 days

IPX rating: IPX6

Battery: 3.7V - 2000mAh

Input Voltage / Current: 5V / 1A

Charge time: 5hr (Approx.)

Dimensions: 90L x 90W x 150Hmm

INTRODUCTION

The Lumos Mozzie Zapper is a compact and lightweight lantern and mozzie zapper suitable for camping, hiking, cycling and climbing. Featuring a UV light and integrated attractant tablets the Lumos Mozzie Zapper provides protection from small insects and bugs that would be attracted to the LED light function of the lantern. A weather resistant rating of IPX6 guarantees that the Lumos Mozzie Zapper can be used under all harsh and demanding conditions.

FEATURES INCLUDE

- Three super bright 1W LEDs generate up to 180 Lumen
- UV LED mozzie zapper
- USB charging port
- Built-in lithium rechargeable battery
- Mozzie attractant tablets
- Built-in hanging hook

CONTENTS

- 1 x LED Lantern Mozzie Zapper
- 1 x USB cable
- 2 x Mozzie attractant tablets

OPERATION

The Lantern and Mozzie Zapper functions can be operated independently or simultaneously

Lantern:

1. Press the Power button for



Mozzie Zapper:

1. Press the Mozzie button



MOZZIE ATTRACTANT

The attractant tablets are designed to release a chemical mixture that replicates the human body and is a natural attractant for mosquitos that draws them to the lantern. The level of attractant that is released can be controlled by adjusting the control on the base of the lantern. Each tablet contains sufficient attractant to last for 25 to 30 days after being removed from its protective packaging.

Installing Attractant Tablet:

1. Disassemble by lifting the hangers on base of lantern



2. Turn in an anti-clockwise direction to release the holder




3. Carefully install or replace the attractant tablet and reinstall to lantern



CHARGING

 Connect the supplied USB cable to the Charging Port




- 2. Connect to a suitable 5V/1 or 2A outlet
- Charge Indicator will illuminate RED and will TURN OFF when fully charged

Note: Appliance can be used when being charged or directly from a suitable power source (the charge time will be increased if in operation whilst being charged).

ADJUSTING LEVEL OF ATTRACTANT

The amount of attractant that the unit will emit can be adjusted by the control located on the base of the unit.



Turn clockwise to increase or anti-clockwise to decrease the amount of attractant released

